



Sink should be supported by flanges only. Sink gets deeper than 8" toward drain. Silicone should NEVER be used with a copper sink! Silicone is fine with stainless sinks. Plumbers putty is recommended with copper and stainless drain/flange installation.

Important: Tell your counter fabricator to cut flush with the interior of the bowl.

NO overhang, NO reveal.

Important: If your faucet choice causes you to lean against the apron of your sink while working, you will likely eventually damage the finish on the apron of your sink. I recommend a faucet reach minimum of 8 3/4" for small sinks and 10" for larger sinks.

Apron to overlay frame of cabinet by 1"



Lifetime Warranty



Kitchen and Bath Products
www.Rachiele.com 1-800-881-9044