



Installation Guidelines for our Top Mount (Self Rimming) Sinks

Installing our top mount sinks is very easy. Simply place the sink in the location you would like it. Use some painters tape to outline the sinks position on the counter top. Remove the sink and use the adhesive caulk to run a bead just inside the taped area. Set the sink in place. Remove the tape. Clean up excess caulk with a damp sponge.

Hook up the plumbing. If the sink does not set exactly flat to the counter, put some weight inside the sink for 12 hours.

Important: Types of caulk to use and NOT use.

I have been told that Silicone caulk is acid based and will react with the copper. If clear Silicone caulk is used, the area where it touches the copper might turn a greenish blue. I have also been told that the non-acrylic Silicone caulk may leach into the granite creating a dark area. NOT RECOMMENDED

The best type of caulk to use is a true acrylic caulk. It is water based and will not react with the copper and will not react with the countertop material. We offer a custom color matched acrylic caulk. Look under the copper sinks tab on our web site for color matched copper sink caulk.

